



RightTemp® Jr. User's Guide

The RightTemp Jr. is designed to monitor and control the temperature of a far infrared warming pad by using animal temperature feedback.

This product is not designed, intended or authorized for use in human applications.

Included Equipment

- (1) Controller
- (1) Far infrared warming pad
- (2) Temperature sensors
- (1) Power Adapter
- (1) Power Cord



Set Up Hardware:

1. Connect the power supply to the back of the controller and flip the power switch to "On".
2. Connect the far infrared warming pad to the "Pad Power" connection on the back of the controller.
3. Secure one of the temperature sensors to the center of the warming pad using tape, then connect the sensor to the "Pad" connection on the back of the controller.
* If using the included disposable pad covers, make sure the sensor is positioned prior to covering the pad.
4. Insert the other temperature sensor into the animal's rectum and secure, then connect the sensor to the "Animal" connection on the back of the controller. Position the animal in the center of the pad directly over the pad sensor.

RightTemp Jr. Settings

Animal Temperature Regulation (requires use of both pad and animal temperature sensors)

1. Use the – and + icons to adjust "Set" temperature, this is your desired animal temperature.
2. The pad will automatically begin warming.
3. Certain colors on the screen advise you as to the status of the warming pad.
 - a. If the arrow on the left side is Blue: the "Body Temperature" is below target.
The warming pad will actively warm to reach "Set" temperature.
 - b. If the circle in the center is Green: "Body Temperature" equals "Set" temperature.
The warming pad will maintain "Set" temperature.
 - c. If the arrow on the right side is Red: "Body Temperature" is above "Set" temperature.
The warming pad will decrease warming until it reaches "Set" temperature.





Unregulated Warming (requires use of pad temperature sensor only)

In unregulated warming mode, the RightTemp Jr. warms the pad, but the warming level is not controlled by animal temperature. Instead, you can control the pad warming by setting the percentage of maximum power going to the pad.

1. Connect the power supply to the back of the controller and flip the power switch to “On”.
2. Connect the warming pad to the “Pad Power” connection on the back of the controller.
3. Secure one of the temperature sensors to the center of the warming pad using tape, then connect the sensor to the “Pad” connection on the back of the controller. If using the included disposable pad covers, make sure the sensor is positioned prior to covering the pad.

Tip: Unregulated Warming does not include any temperature control. The pad can become very hot if used at high warming percentages.

Tip: If you wish to switch from “Animal Temperature Regulation” to “Unregulated Warming” during use, you must remove the animal temperature sensor and recycle power to the controller. To switch back to “Animal Temperature Regulation” simply plug the animal temperature sensor back into the controller.

NOTE: In Unregulated Warming, the “Pad Temperature” is not an indication of “Animal” temperature. Animal temperature can only be regulated when using both sensors in Animal Temperature Regulation Mode.

[FAQ and Troubleshooting](#)

Problem	Possible Cause	Solutions
Pad is not heating to sufficient temperature	Incorrect settings	Ensure that temperature or power is properly set.
	Incorrect sensor placement	Place pad sensor directly beneath the animal.
Pad is overheating	Incorrect settings	Ensure that temperature is properly set.
	Incorrect sensor placement	Place pad sensor directly beneath the animal.
No Sensor Error, or Sensor is reading incorrect temperature	Incorrect sensor placement	Ensure sensor(s) are fully inserted into the back of the controller.
	Pad sensor not working	Contact Kent Scientific for assistance.



Care and Maintenance

- Use the disposable warming pad covers to prevent soiling the warming pad.
- Wipe the controller and warming pad with a damp cloth if needed. Never saturate the warming pad.
- Clean the sensors with germicidal or antiseptic soap and water. Do not use organic solvents or alcohol.

General Information

Thank you for purchasing the RightTemp Jr. We truly appreciate your business. We strongly advise that you read and study this User's Guide to appreciate fully all the features, benefits, and capabilities of the RightTemp Jr.

Contact Information

Kent Scientific Corporation
1116 Litchfield Street
Torrington, Connecticut 06790
E-mail: sales@kentscientific.com

Toll-Free: 888-5RATTUS (888-572-8887)
Outside US: 860-626-1172
Fax: 860-626-1179
Internet: www.kentscientific.com

Disclaimer

Kent Scientific Corporation makes no representations or warranties, expressed, statutory or implied, regarding the fitness or merchantability of the components of this system for any particular purpose. Further, Kent Scientific Corporation is not liable for any damages, including but not limited to, lost profits, lost savings, or other incidental or consequential damages arising from ownership or use of these products, or for any delay in the performance of its obligations under the warranty due to causes beyond its control. In no case shall Kent Scientific Corporation's financial obligation extend beyond the cost of or replacement of the Kent product in question. Kent Scientific Corporation also reserves the right to make any improvements or modifications to these products described in this Guide at any time, without notice of these changes. All brand and product names used in this Guide are the trademarks of their respective owners.

This product is not designed, intended or authorized for use in human applications.